



## V6 & V8 Door Kick Panel Installation Instructions



Congratulations! On your purchase of the V6 & V8 Door Kick Panels we, know that you will enjoy having this great product in your Camaro. If you purchase one of the aluminum one we recommend if you are going to paint door kick panels yourself is to clean it with brake cleaner or something similar. This will remove any dirt, oils and finger prints that might be on it. If you have purchase one of our powder coated or mirrored covers don't use any cleaner on it that might harm the appearance. The powder coated ones don't have a clear coat on them like your Camaro does.

Please READ all of the installation instruction before trying to install the Door Kick Panels and do not skip any steps. If you don't follow these instructions we can't guarantee that they will stay in please. Note: Depending on what hot climate you live in you might have to adjust them.

**Step One:** To install your door kick panels leave the vinyl coating on while you are installing the door kick panel so, you don't scratch it or get finger prints on it. If you purchase the powder coated ones might want to put some painters tape on the finish said while you install them so, you don't scratch them.



**Step Two:** Make sure that you clean your door where the panels are going to go with alcohol and let it dry and, then clean it again with alcohol. Make sure that it is completely dry before installing the door kick panels.

**Step Two:** We recommend using 3M Tape Primer 94 Adhesion Promoter Pen (not included) before peeling the 3M tape.

**Step Three:** Some people like using a clear silicone automotive adhesive to hold them in place and you will have to temporary tape them to the door over night for your silicone adhesive to dry but, make sure that they are on straight. If you don't want to use silicone skip this step and step 4.

**Step Four:** Leave your door open a crack and don't slam the door shut until the silicone adhesive is dry. Come back and check on the door panels to see they the tape you installed didn't come off and the panels didn't come loose.

**Step Five:** After you install the door kick panels then, remove the vinyl coating if you purchase the mirrored ones. Or the painters tape on the finish side if you purchase the powder coated ones.

**Step Six:** Congratulations! You are finish. Enjoy! Your New Door Kick Panels

## **Cleaning Instructions**

To maintain the appearance, be sure to only use a polish suitable for mirrored stainless steel and, only apply polish with a 100% microfiber cloth. Remember, mirrored stainless steel scratches easily. So be sure to be careful when cleaning. Also if you have purchase one of our powder coated one that you use a mild soap and use your hand to clean them and for drying it use a soft microfiber cloth and blotting it, rubbing on it might scratch the finish.

**Note:** There may be some lines on the underside from handling and, making it which you will not see once you install it in your Camaro. This product will come with protecting vinyl just simply pull off the protective vinyl to expose the beautiful mirrored finish. There may be some residue from where the laser cut through the vinyl which you can remove with 100% alcohol and a cotton pad.

