



2010 - 2014 5th Gen Camaro V6 & V8 A/C Vent Trim Upper Dash Installation Instructions



Congratulations! On your purchase of the A/C vent trim we, know that you will enjoy having this great product in your Camaro.

Time needed for this job is about 10 mins, 5 mins for each side. You will not need any tools with you at the car. If it takes you longer do not worry. Take your time, and work at a comfortable pace. Please completely read these instructions prior to beginning. It will only take you a few minutes to read. Do not skip any of the steps.

CAUTION: Stainless is very sharp and blood will stains the A/C vent trim.

Step One: Make sure that you clean the A/C vent trim with 100% alcohol with a cotton ball or pad. Make sure that it's completely dry before you continue.

Step Two: Trial fit the pieces before removing the back adhesive.



Step Three: Peel back a small piece on each side of the vinyl enough so, you can grab it with each hand so, you can place it before you stick it to the A/C vent trim.

Step Four: Peel off all of the adhesive from the back and maneuver the A/V vent trim over your existing vent to place it to your liking. Make sure that press the piece in place.

Step Five: Continue doing the same thing on all of the pieces.

Step Six: After you have finish installing both pieces then finish removing all of the vinyl and, you will see very small residue on the edges from where the laser cut the piece and melted the plastic vinyl. To remove this off without scratching the surface use 100% alcohol and a cotton pad saturated in the alcohol rubbing it as you go. After you are finish use a mild cleaner to bring back the mirrored shine. We recommend using Adam's detail spray or something similar.

Step Seven: Congratulations! You are finish. Enjoy you're A/C Vent Trim.

Cleaning Instructions

To maintain the appearance, be sure to only use a polish suitable for mirrored stainless steel and only apply polish with a 100% microfiber cloth or shammy. Remember, mirrored stainless steel scratches easily. So be sure to be careful when cleaning it.

Note: There may be some lines on the underside from handling and, making it which you will not see once you install it in your Camaro. This product will come with protecting vinyl just simply pull off the protective vinyl to expose the beautiful mirrored finish. There may be some residue from where the laser cut through the vinyl which you can remove with 100% alcohol and a cotton pad.

